



Tel.: 416 520-4080
Fax: 416 519-4172
info@alarvac.com

3868 Chesswood Dr.
Toronto, ON M3J 2W6
www.alarvac.com

TX3 INTERCOM PROGRAMMING

Step 1: press "9999" On the keypad

Step 2: select "CONFIGURATION" (press the green telephone symbol)

Step 3: Password "3333"(if required)

Step 4: Scroll down to "DATA BASE"(press green telephone symbol)

Step 5: Select "EDIT" (press green telephone symbol)

Step 6: Scroll to resident you wish to edit (press green telephone symbol)

Step 7: Edit telephone number (press green telephone symbol)

Step 8: EXIT by pressing the "I" symbol